

PNÖMATİK OTOMATİK HORTUM FITİNGSLERİ PNEUMATIC PUSH IN TUBE FITTINGS

OTOMATİK DİRSEK BAĞLANTILAR PUSH IN ELBOW FITTING


MODEL PN-VP



SİPARİŞ KODU ORDER CODE	ØD HORTUM DIŞ ÇAPI HOSE EXTERNAL DIA. (MM)
PN-VP	4
PN-VP	6
PN-VP	8
PN-VP	10
PN-VP	12
PN-VP	14
PN-VP	16

OTOMATİK YE BAĞLANTILAR PUSH IN Y SHAPE FITTINGS


MODEL PN-PY



SİPARİŞ KODU ORDER CODE	ØD HORTUM DIŞ ÇAPI HOSE EXTERNAL DIA. (MM)
PN-PY	4
PN-PY	6
PN-PY	8
PN-PY	10
PN-PY	12

OTOMATİK TE BAĞLANTILAR PUSH IN T SHAPE FITTINGS

MODEL PN-EP



SİPARİŞ KODU ORDER CODE	ØD1 HORTUM DIŞ ÇAPI HOSE EXTERNAL DIA. (MM)
PN-EP	4
PN-EP	6
PN-EP	8
PN-EP	10
PN-EP	12
PN-EP	14
PN-EP	16

OTOMATİK ORANTILI TE BAĞLANTILAR PUSH IN T SHAPE REDUCING FITTING

MODEL PN-GEP



SİPARİŞ KODU ORDER CODE	HORTUM DIŞ ÇAPI HOSE EXTERNAL DIA. ØD1	HORTUM DIŞ ÇAPI HOSE EXTERNAL DIA. ØD2
PN-GEP	6	4
PN-GEP	8	6
PN-GEP	10	8
PN-GEP	12	10
PN-GEP	16	12

OTOMATİK HORTUM GİRİŞLİ 4 LÜ YE BAĞLANTI PUSH IN DOUBLE Y TYPE FITTING

MODEL PH-GXP



SİPARİŞ KODU ORDER CODE	HORTUM DIŞ ÇAPI HOSE EXTERNAL DIA. (MM) ØD	HORTUM DIŞ ÇAPI HOSE EXTERNAL DIA. (MM) ØD1
PH-GXP	6	4
PH-GXP	8	6

OTOMATİK YE TİP ADAPTÖRLER PLUG IN Y TYPE FITTING

MODEL PN-JYP



SİPARİŞ KODU ORDER CODE	HORTUM DIŞ ÇAPI EXTERNAL DIA. ØD2	HORTUM DIŞ ÇAPI HOSE EXTERNAL DIA. ØD1
PN-JYP	4	4
PN-JYP	6	6
PN-JYP	8	8
PN-JYP	10	10
PN-JYP	12	12